





INSTRUCTIONS FOR USE AND INSTALLATION Original instructions

Read these instructions carefully before installation and use.

Available also on www.valera.com

Hairdryer Type 832.01/.., **832.02**/.., **832.10**/.. R=with shaver socket

110-120V / 220-240V max 20VA T=with 8 minute timer

CAUTION

English

- Before use, the appliance must be fitted and properly installed by a qualified electrician.
- Important: In order to guarantee additional protection, it is recommended that a differential breaker with an intervention current not greater than 30 mA is installed in the electrical system which feeds the device. For further information, contact a qualified electrician.
- Make sure the electrical system is fitted with a device which guarantees omnipolar disconnection from the electricity mains under category Ill overvoltage conditions.
- Make sure the unit is perfectly dry before using it.
 - WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.
- This appliance can be used by children from 8 years of age and over, and by persons with limited physical, sensory or mental abilities or who lack the relevant experience and knowledge, if they are suitably supervised or have been educated to use the appliance safely and made

- aware of the associated risks.
- Do not allow children to play with the appliance.
- Children must not perform cleaning and maintenance procedures unless supervised.
- Only connect the appliance to an alternate current power supply, and make sure that the mains voltage corresponds to the one indicated on the appliance.
- Make sure that the air inlet grills at the bottom of the appliance are never obstructed.
- Do not use your unit if it is not working properly. Do not try to repair this electrical unit yourself, rather contact an authorized technician. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or a similarly qualified person in order to avoid a hazard.
- The elements used to pack the appliance (plastic bags, cardboard box, etc...) must not be left within reach of small children, as they are a potential source of danger.
- This appliance must only be used for the purposes for which it has been specifically designed: to dry hair (for models 832.01/R, 832.02/R, 832.10/R also to operate and recharge electric razors, max 20VA). Any other use is to be considered improper and therefore dangerous. The manufacturer will not be considered liable for any damage deriving from improper or incorrect use of the appliance.



Date of purchase	Innkjøpsdato	Data zakupu	Дата покупки
Kaufdatum	Inköpsdatum	Datum kupnje	تاريخ الشراء
Date d'achat Data d'acquisto Fecha de adquisición Datum aankoop Data de compra	Ostopäivämäärä Købsdato Eladás dátuma Datum prodeje Data cumpārārii	Нµєроµηνία αγοράς Satın alma tarihi Dátum nákupu Дата на закупуване Дата покупки	购买日期 تاریخ الشراء

Naam en adres van de consument Nome e endereco do cliente Kiøperens fullstendige navn og adresse Köparens namn och fullständig adress Ostaian nimi ia tävdellinen osoite Køberens fulde navn og adresse Vevő neve éstelies cime Jméno a adresa záhaznika Numele i adresa completă a comparatoruluii Nazwisko oraz pelny adres kupującego lme i adresa kupca Όνομα, επώνυμο και πλήρης διεύθυνση του αγοραστή Alıcının tam ismi ve adresi Meno a celá adresa kupujúceho/zákazníka Име, фамилия и пълен адрес на купувача Прізвище, ім'я, по батькові і повна адреса покупця Фамилия/имя и полный адрес покупателя اسم المشترى و عنو انه الكامل 购买人完整姓名和地址 نام و نشانی کامل خریدار

Name and full address of purchaser

Name und vollständige Anschrift des Käufers

Nom et adresse completè de l'acheteur

Nome e indirizzo completo dell'acquirente

Nombre v dirección completa del comprador

- The A-weighted sound pressure level of the hairdryers for commercial use is below 70 dB(A).
- Designation of the appliance (see technical product specifications) WALL-MOUNTED HAIRDRYER FOR COMMERCIAL USE

IMPORTANT

This appliance complies with safety requirements for electrical equipment.

This hairdryer is fitted with a safety thermostat. It will stop automatically if it overheats. After a short time it will start up again.

Before use, make sure that the appliance air inlet grills are perfectly clean.

The manufacturer will not be considered liable for any damage to persons or property deriving from failure to comply with the above recommendations, or improper use of the hairdryer. This appliance conforms to European Directives 2014/30/EU, 2014/35/EU, 2011/65/EC, 2009/125/EC and Regulation (EC) No. 1275/2008.

INSTRUCTIONS FOR USE

To start the hairdryer, remove the handpiece from its housing. Models 832.01/R, 832.02/R, 832.10/R are fitted with 110-120V and 220-240V, 50/60 Hz~ shaver sockets.

These sockets, which can be accessed by lifting a special protection flap (fig. 5), must only be used to run or recharge electric shavers (max 20VA).

IMPORTANT: never connect other appliances such as electric coffee machines, heaters, etc. to these sockets.

Models 832.01/T, 832.02/T, 832.10/T are fitted with an electric timer which turns the appliance off automatically after a pre-set time (8 min.). To turn it back on again, simply replace the handpiece in its housing and then remove it again.

CLEANING AND MAINTENANCE

Plastic components must be cleaned using a cloth damped in warm water.

WARNING: do not use abrasive products or chemical detergents.

A slight yellowing of the flexible hose after a few months of use is normal and will not impair operation of the appliance.

INSTRUCTIONS FOR INSTALLATION WARNING: this operation must be carried out by a qualified

technician.
Check that the local power supply corresponds with the one

check that the local power supply corresponds with the one indicated on the rating plate.

The power supply network to which the appliance is connected must be fitted with a omnipolarebeli switch.

The appliance is destined for assembly and installation on a wall only (vertical). The correct direction of installation is with the extending pipe outlet at the bottom.

This hairdryer is an approved product with protection degree IP34 (EN60529). For installation specifications, please refer to national regulations on the use and installation of appliances with IP34 protection from splashing. If the power cable with plug fitted to the appliance is used, the power

socket to which it is connected must be out of reach of possible water splashes.

Mounting sequence

- Insert the power plug into the power socket only when the installation is completed.
- 2. After establishing the position in which the appliance is to be installed, drill 3 holes Ø 6 mm in the wall as shown in fig. 1.
- 3. Dismantle the "T" bracket from the back of the appliance, as shown in figure 2.
- 4. Fix the "T" bracket to the wall using the screws and plugs provided (fig. 3).
- 5. Hang the appliance on the "T" bracket and fix it at the bottom using the screw provided (fig. 4).

GUARANTEE

VALERA guarantees the appliance you have bought at following conditions:

- 1. The guarantee conditions for this appliance are as defined by our dealer in the country of sale. In Switzerland and the countries of the European Union, the warranty period is 24 months if the final purchaser is a private person (domestic use) and 12 months if the final purchaser is a company or business or professional (professional use). The guarantee period starts from the date of purchase as stated on the present guarantee card regularly filled out and stamped by the dealer or on the sale's invoice.
- The guarantee is applicable only against submission of the present quarantee card or the sale's invoice.
- 3. The guarantee covers the elimination of all defects arisen during the guarantee period resulting from proven faults in material or workmanship. The elimination of the defects will be made either by repairing the appliance or exchanging it. The guarantee does not cover any damage arising from incorrect connection to the power supply, improper use, breakage, normal wear and non-compliance with the Instructions for Use.
- All other claims of any nature, including those for eventual damages outside of the appliance, are excluded, unless our liability is legally mandatory.
- The guarantee service is carried out free of charge; it does not affect the expiry date of the guarantee.
- The guarantee becomes void if repairs are under-taken by unauthorized persons.

For UK only: this guarantee in no way affects your rights under statutory law.

In case of defect, please return the appliance well packed and together with the guarantee card regularly dated and stamped to one of our Valera Service Centres or to the dealer who will send it to the official importer for the guarantee service.

The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

VALERA is a registered trade mark of Ligo Electric S.A. - Switzerland